


PARTS VALUES FOR DCF77
CONRAD MODULE 190691 WITH ANTENNA 536008
R101 - 1K
R102 - 1K5

CONRAD MODULE 641138 INCLUDING ANTENNA
R101 - 120
R102 - NOT MOUNTED

CONRAD MODULE 641138 IS PREFERRED

ALWAYS PLACE DCF77 RECEIVER AT 1 METER DISTANCE AWAY FROM CLOCK !!!

RTC CLOCK OPTION
TYPICALLY, THE RTC CAN RUN FOR 2 DAYS WITHOUT POWER
CLOCK MAY GAIN OR LOOSE A SECOND IN BACKUP MODE



Title **Nixie Controller**

Revision: 1.0 WWW.FRANKTECHNIEK.NL

Date: 11-Sep-2004 Time: 00:18:09 Sheet1 of 2

File: C:\Mijn documenten\Boards\Nixie\N16-4-Rev1\Nixie\N16-4-1.ddb - Documents\N16-4-1-Micro.Sch

